

Development of a Canopy Air Curtain to Reduce Roof Bolters' Dust Exposure

Jeffrey M. Listak and Timothy W. Beck

February 20, 2012
SME Annual Meeting



Problem

Roof bolter operators' rate of over-exposure to respirable dust is second only to the continuous miner operator.

The main source of this over-exposure is working downwind of the continuous mining machine.




Operational Facts

- **Roof bolter operators continue to work downwind of the CM.**
- **MSHA is requiring more CM machines to operate without scrubbers, even though scrubbers greatly reduce respirable dust in the return.**
- **The impending dust rule will reduce respirable dust exposure lower than the current 2 mg/m³ standard.**



Addressing the Problem

Develop a retrofit system to deliver a curtain of clean air over operators when performing drilling activities beneath the canopy.




Air Curtain Development

- 1975 – The Donaldson Co. Inc., under contract from the USBM, demonstrates that air curtain technology can protect CM operators from respirable dust while working in onboard cabs.
- 1982 – USBM report shows respirable dust reductions on gathering-arm loaders operators fitted with air curtain system.
- 1987 – The Donaldson Co. Inc. improves original air curtain design. Newer design improved airflow, decreased thickness, and decreased noise levels.



Design Changes for Bolters

- Plenum geometry dimensions based on typical canopy size and shape.
- Inlet port located parallel to length of plenum length.
- Blower powered by a dedicated hydraulic motor and reservoir.



Laboratory Test Apparatus

Air Curtain Test Setup



Plenum Test Stand




Fan-Filter Assembly





Plenum Design Objective

Achieve even airflow distribution beneath the plenum



Plenum Testing

Computational Fluid Dynamics (CFD) Analysis



Plenum Testing

Airflow visualization using smoke




Preliminary Field Trials

- **Identified region of unneeded coverage**
 - Canopy overlaps operator's tool tray
- **Demonstrated feasibility of design**
 - Acceptable impact on overhead clearance
 - Hydraulic fan provides adequate air quantity




Plenum Testing

Final Plenum Design




Air Distribution


Post-CFD Design




Final Design



Full-Scale Testing



Sampling for Dust Reduction





Test Methods

- Full-scale testing conducted in the continuous mining simulation gallery at the OMSHR laboratory.
- Respirable dust sampled at entry velocities of 0.03 (10), 0.30 (60), and 0.61 (120) m/s (fpm).
- Respirable dust concentration held constant for all test velocities (average of 6.0 mg/m³).
- Respirable dust concentrations measured with gravimetric samplers and Personal Data Ram.
- Six test replicates for each velocity.
- Sample in open entry and beneath the plenum.




Sampling Locations




Dust Reduction Across Tests

Test	Dust Concentration, mg/m ³	
	Plenum	Entry
1	1.62	4.48
2	1.41	4.57
3	1.70	5.13
4	1.63	4.78
5	1.36	4.56
6	2.42	6.52



Dust Reduction Across Entry Velocities



Laboratory Results

- Final design provides filtered air coverage over 70% of plenum area: velocity > 0.51 m/s (100 fpm).
- Plenum provides area of confirmed dust reductions at entry velocities up to 0.61 m/s (120 fpm).
- No significant difference in dust exposure reductions in the three entry velocities tested.
- Dust reductions of 67% to 75% was achieved beneath the plenum at each of the test velocities.



Field Testing



Field Testing Results

- **Based on time studies, bolter operators spent about 66% of a complete bolting cycle beneath the plenum (tram in to tram out of place).**
- **Integrating the blower into the machine's hydraulic system proved to be problematic.**
- **Limited PDM (194 min) data showed a reduction of 34% between the dual boom bolter operators (left side vs right side) during sampling.**



Alternate Design



Questions?

Jeffrey M. Listak

412-386-5082

Email: jlistak@cdc.gov

Timothy W. Beck

412-386-4776

Email: tbeck@cdc.gov

Disclaimer: Mention of any company or product does not constitute endorsement by the National Institute for Occupational Safety and Health (NIOSH). The findings and conclusions in this presentation are those of the authors and do not necessarily represent the views of NIOSH.

